

Butterfly lamp manual

Thank you very much for purchasing our company's LED smart butterfly lamp. For your personal safety and better use of this product, please read this manual carefully before use and follow the procedures..

●technical parameters:

power supply : AC90~240V , 50Hz~60Hz

rated power : 50W

The light source : 20W (RGBW) LED

Yan color Colorful:

control mode: DMX-512、Since walking pattern、 Sound control mode

●maintain :

As far as possible, dust, dirt and tobacco oil are put into the lamp, and the environment is used to keep the LED clean.Please use the professional glass cleaner regularly and clean the reflector with flannelette every month..

●Digital display control button.

MENU UP DOWN ENTER



MENU menu key to select functional mode., UP, DOWN Key: it is the add and subtract regulation key, ENTERKey: determines the key, press the key to select the mode will be saved.

1	A001	DMX512 (enter switch to channel mode selection)
2	A1-9	Red self-walking mode (slow to fast, adjustable speed of motor)
3	A2-9	Green self-walking mode (from slow to fast, adjustable speed of motor)
4	A3-9	Blue self-walking mode (from slow to fast, adjustable speed of motor)
5	A4-9	White self-walking mode (from slow to fast, adjustable speed of motor)
6	A5-9	Color monochrome jump start mode (slow to fast, adjustable speed of motor)

7	A6-9	Color mixing and jumping mode (from slow to fast, adjustable speed of motor)
8	A7-9	Color gradient self-walking mode (from slow to fast, adjustable speed of motor)
9	A8-9	Color frequency flash mode (from slow to fast, motor speed adjustable)
10	51-20	Voice control mode, without sound stimulation, the default is slow to jump.
11	52-20	Voice control mode, default sleep mode without sound stimulation.

一、
function set

二、 DMX Control channel mode (A001-A512)

	Channel value	functional description
1	001-255	Color master switch adjustment function.
2	001-255	Red, from dark to bright to adjust the brightness function.
3	001-255	Green, from dark to bright adjust brightness function.
4	001-255	Blue, from dark to bright to adjust the brightness function.
5	001-255	White, from dark to bright to adjust the brightness function.
6	001-255	From slow to fast adjust stroboscopic function.
7	001-255	Motor rotation, motor left and right direction and speed adjustment function
8	001-255	Self - walk, gradient, jump, stroboscopic, voice - control function.