

#### 4. IR Remote Control Instruction

**Note:** Before using the remote control, please pull out the plastic sheet under the remote control so that the remote control can work.

ON	Since go	
OFF	close	
DMX	DMX pattern	
AUTO	Go, every press from walk function switch	
speed+	Speed increase	
speed-	Speed slowed down	
voice	Voice control, each press of the voice control switch	
mic+	Sound-control sensitivity increases	
mic-	Sound-control sensitivity is reduced	
1	Combination from walk 1	
2	Combination from walk 2	
3	red LED	
4	green LED	
5	blue LED	
6	white LED	
7	LED from the walk	
8	Laser self-walking effect	
9	Flash from the effect	
0	sound control	

## The Butterfly Kaleidoscope Use Manual



Thank you for purchasing our product  
Please Read Over This Manual Before Operating The Light Fixture

### 1. Product technical parameters

1. Operating voltage: AC95V-245V 50 / 60Hz
2. Rated power: 70W
3. parameters: 1pcs15W 4-in-1 lamp bead, 4pcs10W white strobe, 4pcs100 mW red laser, 4pcs30 mW green lasers
4. Control mode: international general DMX512, 12 channel
5. Working mode: DMX512, master / slave, self-walking, voice control
6. Dimming mode: 0~100% super smooth dimming
7. Strobe: 20 times / second

### 2. Function settings

menu	numeric value	description	
d__	001~512	Console mode or slave mode	
A1~2	1~9	Integrated mode, the larger the value, the faster the motor speed	
E1~7	1~9	In LED mode, the larger the value, the faster the motor speed	
F1~2	1~9	In strobe mode, the larger the value, the faster the strobe speed	
P 1~2	1~9	8 In Laser mode, the larger the value, the faster the speed	
SOU_	1~4	Voice-control mode, 4 mode choices	
VOL_	1~9	Sound-control sensitivity adjustment Larger the numerical values, and then, the higher the sensitivity	Pressthe "ENTER" keyforfive seconds toentertheseconda ry menu
ir_	0 n/OF	Remote control / turn off	
The "MENU" menu key,ENTER storage confirms health "UP" and "DOWN" motor speed adjustment and DMX512 address adjustment, Sound control sensitivity adjustment and remote control switch switch under the secondary menu.			

### 3.DMX control

channel	The channel value	functional description
CH 1	0~127	LED motor placement
	128~255	The LED motor is positively reversed, with the speed varying from slow to fast
CH 2	0	Closed light
	1~255	Total dimming
CH 3	0	No flash
	1~255	Strobe speed is from slow to fast
CH 4	0	White Light COB, no strobe
	1~255	White light COB strobe speed from slow to fast
CH 5	0	Red LED closed light
	1~255	Red LED brightness is linearly regulated from dark to bright
CH 6	0	Green LED closed light
	1~255	Green LED brightness is linearly regulated from dark to bright
CH 7	0	Blue LED closed light
	1~255	Blue LED brightness is linearly regulated from dark to bright
CH 8	0	White LED closed light
	1~255	White LED brightness is linearly regulated from dark to light
CH 9	0	4 White Light COB closed light
	1~255	The brightness of the four white light COB is adjusted linearly, from dark to light
CH 10	0	Eight laser lights were closed
	1~255	The 8 lasers are linearly adjusted from dark to bright
CH 11	0~10	CH1~CH11 valid
	11~45	LED saltus step
	46~80	Mixed color jump 1
	81~115	Mixed color jump 2
	116~150	Sound control 1
CH 12	151~185	Sound control 2
	0~255	Speed has been slow to fast (sensitivity from slow to fast) CH11 effective